

**ANGUS GLEN ARENA
CLOCK INSTRUCTIONS
(3 X 10 Minute Stop Time Periods)**

To Set Up and Start Game:

1. Press NEW GAME.
2. Press CLEAR.
3. Press 1 for time to count down. Press ENTER.
4. PERIOD MINUTES should appear. Press 10. Press ENTER twice. The clock should display 10 minutes.
5. Press AUTO HORN. Press 0 seconds to disable auto horn. Press ENTER.
6. Press TIMER RUN every time the referee drops the puck.
7. Press TIMER STOP every time the referee blows the whistle to stop the play.
8. After the first period is over, press PERIOD. PERIOD #2 should appear. Press ENTER. PERIOD MINUTES should display 10. Press ENTER twice. Repeat this step to set the clock for the third period.

To Enter Goals:

1. Press HOME or GUEST button to enter a goal.

To Correct a Goal Entered in Error:

1. Press RECALL.
2. Press HOME or GUEST button depending on which score needs to be corrected.
3. Enter the correct score using the keypad numbers.
4. Press ENTER.

To Enter Penalty:

1. Press PENALTY button under HOME or GUEST as applicable.
2. Press 2 using the keypad numbers for 2 minute penalty or another number as needed.
3. Press ENTER twice.

To Clear a Penalty:

1. Press RECALL.
2. Press PENALTY under the HOME or GUEST button depending on which penalty needs to be cleared.
3. Press CLEAR.
4. Press ENTER.